

LAOKANGAD (sorteeritud kataloogi numbri järgi)

Kood	Nimetus	Värvus	Laius	Kataloog	Tüüp
2-20327	Butterfly Pearl	h.hall	220	1	tava
2-21006	Butterfly Pearl	valge	220	1	tava
2-21077	Butterfly Pearl	kreem	220	1	tava
2-22080	Butterfly Pearl	kollane	220	1	tava
2-22087	Butterfly Pearl	beež	220	1	tava
2-22178	Butterfly Pearl	h.pruun	220	1	tava
2-22350	Butterfly Pearl	kuldne	220	1	tava
2-22370	Butterfly Pearl	beežikashall	220	1	tava
2-22372	Butterfly Pearl	beež	220	1	tava
2-22380	Butterfly Pearl	h. kollane	220	1	tava
2-24061	Butterfly Pearl	roheline	220	1	tava
2-24151	Butterfly Pearl	roheline	220	1	tava
2-24750	Butterfly Pearl	t.beež	220	1	tava
2-25148	Butterfly Pearl	h.sinine	220	1	tava
2-25149	Butterfly Pearl	sinine	220	1	tava
2-25194	Butterfly Pearl	sinine	220	1	tava
2-26051	Butterfly Pearl	t. kollane	220	1	tava
2-29091	Butterfly Pearl	hall	220	1	tava
2-29113	Butterfly Pearl	must	220	1	tava
1-5489	Dance	valge	210	2	tava
1-5490	Dance	beež	210	2	tava
1-5491	Dance	hall	210	2	tava
1-5945	Dance	kreem	210	2	tava
1-5944	Dance	roheline	210	2	tava
0-11029	Opera Pearl	valge	220	4	tava
0-11048	Opera Pearl	kreemjas	220	4	tava
0-12320	Opera Pearl	beež	220	4	tava
0-12371	Opera Pearl	beež	220	4	tava
0-12372	Opera Pearl	beež	220	4	tava
0-12381	Opera Pearl	pruun	220	4	tava
0-12382	Opera Pearl	kollakas	220	4	tava
0-12383	Opera Pearl	pruun	220	4	tava
0-13067	Opera Pearl	oranž	220	4	tava
0-13072	Opera Pearl	t. kollane	220	4	tava
0-14159	Opera Pearl	sinakas	220	4	tava
0-14160	Opera Pearl	sinakas	220	4	tava
0-14161	Opera Pearl	rohekas	220	4	tava
0-14163	Opera Pearl	roheline	220	4	tava
0-15200	Opera Pearl	sinine	220	4	tava
0-15201	Opera Pearl	sinine	220	4	tava
0-16065	Opera Pearl	kollakas	220	4	tava
0-16113	Opera Pearl	kollakas	220	4	tava
0-18159	Opera Pearl	roosa	220	4	tava

LAOKANGAD (sorteeritud kataloogi numbri järgi)

Kood	Nimetus	Värvus	Laius	Kataloog	Tüüp
0-18160	Opera Pearl	lilla	220	4	tava
0-18161	Opera Pearl	punane	220	4	tava
0-19090	Opera Pearl	hall	220	4	tava
0-19178	Opera Pearl	hall	220	4	tava
0-19179	Opera Pearl	t. hall	220	4	tava
0-19180	Opera Pearl	must	220	4	tava
0-19181	Opera Pearl	hall	220	4	tava
0-19186	Opera Pearl	hall	220	4	tava
0-19244	Opera Pearl	pruun	220	4	tava
0-19245	Opera Pearl	hall	220	4	tava
0-19248	Opera Pearl	beež	220	4	tava
1-221	Twist Pearl	valge	220	6	tava
1-222	Twist Pearl	kreemjas	220	6	tava
1-226	Twist Pearl	hall	220	6	tava
1-227	Twist Pearl	hall	220	6	tava
1-232	Twist Pearl	hall	220	6	tava
1-234	Twist Pearl	helehall	220	6	tava
1-235	Twist Pearl	kreemjas	220	6	tava
2-101	Falliero Met	valge	230	7	tava
2-102	Falliero Met	hõbedane	230	7	tava
2-103	Falliero Met	must	230	7	tava
2-1044	Falliero Met	kuldne	230	7	tava
2-1088	Falliero Met	hõbe	230	7	tava
1-0432	Samba Pearl	roheline	240	7	tava
1-0459	Samba Pearl	h hall	240	7	tava
1-0460	Samba Pearl	hall	240	7	tava
1-7702	Samba Pearl	valge	240	7	tava
1-7703	Samba Pearl	kreemjas	240	7	tava
1-7704	Samba Pearl	beež	240	7	tava
1-7705	Samba Pearl	liiv	240	7	tava
1-7706	Samba Pearl	pruun	240	7	tava
2-1069	Nabucco	valge	220	11	tava
2-2274	Nabucco	beež	220	11	tava
2-2276	Nabucco	pruun	220	11	tava
2-2294	Nabucco	pruun	220	11	tava
2-2295	Nabucco	pruun	220	11	tava
2-5722	Nabucco	beež	220	11	tava
2-9154	Nabucco	hall	220	11	tava
2-9155	Nabucco	hall	220	11	tava
2-2345	Rumba	kreemjas	240	11	tava
2-2346	Rumba	beež	240	11	tava
2-2347	Rumba	oranžikas	240	11	tava
2-2348	Rumba	pruun	240	11	tava

LAOKANGAD (sorteeritud kataloogi numbri järgi)

Kood	Nimetus	Värvus	Laius	Kataloog	Tüüp
2-7779	Pasodoble	beež	240	11	tava
2-7780	Pasodoble	hall	240	11	tava
2-7781	Pasodoble	hall	240	11	tava
2-7826	Pasodoble	pruun	240	11	tava
2-8216	Pasodoble	hall	240	11	tava
2-8261	Pasodoble	oranžikas	240	11	tava
3-7950	Gioconda BO	valge	215	12	tava pimendav
3-7951	Gioconda BO	kreemjas	215	12	tava pimendav
3-7952	Gioconda BO	beež	215	12	tava pimendav
3-7953	Gioconda BO	hall	215	12	tava pimendav
3-7954	Gioconda BO	hall	215	12	tava pimendav
3-7955	Gioconda BO	hall	215	12	tava pimendav
3-7639	Scala BO	valge	230	12	tava pimendav
3-20327	Opera Dimout	hall	210	13	tava
3-21000	Opera Dimout	valge	210	13	tava
3-22054	Opera Dimout	beež	210	13	tava
2-5021	Zumba	kreemjas	235	13	tava
2-5026	Zumba	hall	235	13	tava
2-5033	Zumba	hall	235	13	tava
1-8048	Opera Metallic	hele hõbe	220	15	tava
1-8049	Opera Metallic	hall	220	15	tava
1-8050	Opera Metallic	grafiit	220	15	tava
1-8051	Opera Metallic	valge	220	15	tava
1-8031	Opera Print	ice, helehall	220	15	tava
S-8150	Disco	kreem	250	HC	kärg
S-8151	Disco	valge	250	HC	kärg
S-8152	Disco	kreem	250	HC	kärg
S-8153	Disco	heleroheline	250	HC	kärg
S-8154	Disco	helesinine	250	HC	kärg
S-8155	Disco	h. pruun	250	HC	kärg
S-8156	Disco	lillakas-hallikas	250	HC	kärg
S-8157	Disco	t. hall	250	HC	kärg
S-8158	Disco	roosa	250	HC	kärg
S-8159	Disco	lillakas	250	HC	kärg
S-8160	Disco	helehall, roosaks	250	HC	kärg
S-8161	Disco	pruun	250	HC	kärg
S-8162	Disco	h.hall	250	HC	kärg
S-8165	Disco	roheline	250	HC	kärg
S-8166	Disco	hall	250	HC	kärg
S-8169	Disco	must	250	HC	kärg
S-8170	Disco	h. kollane	250	HC	kärg
S-8171	Disco	kreem	250	HC	kärg

LAOKANGAD (sorteeritud kataloogi numbri järgi)

Kood	Nimetus	Värvus	Laius	Kataloog	Tüüp
A-9201	Disco BO	h. hall	250	HD	kärg pimendav
A-9202	Disco BO	lilla	250	HD	kärg pimendav
A-9203	Disco BO	roheline	250	HD	kärg pimendav
A-9204	Disco BO	t. beez	250	HD	kärg pimendav
A-9205	Disco BO	pruun	250	HD	kärg pimendav
A-9206	Disco BO	kreem	250	HD	kärg pimendav
A-9207	Disco BO	hallikas- beežikas	250	HD	kärg pimendav
A-9208	Disco BO	hallikaskreem	250	HD	kärg pimendav
A-9209	Disco BO	t. sinine	250	HD	kärg pimendav
A-9210	Disco BO	heleroheline	250	HD	kärg pimendav
A-9211	Disco BO	helesinine	250	HD	kärg pimendav
A-9212	Disco BO	beez	250	HD	kärg pimendav
A-9214	Disco BO	kollakas-beez	250	HD	kärg pimendav
A-9218	Disco BO	h hall	250	HD	kärg pimendav
A-9219	Disco BO	h hall	250	HD	kärg pimendav
A-9220	Disco BO	h hall	250	HD	kärg pimendav
A-9221	Disco BO	must	250	HD	kärg pimendav
A-9223	Disco BO	roosa	250	HD	kärg pimendav
A-9226	Disco BO	h lilla	250	HD	kärg pimendav